



Use the outrigger base to find the correct position on each side of the boat. Mark around each foot then use this template as a drill jig.

Bolt is M10  
Recommended drill size 11mm

Foot and knuckle at the base of the main pole MUST be inline and run straight with the main pole

